


HALF SCREEN INSTALLATION & REMOVAL GUIDE

Begin by opening or tilting the lower sash of your window toward the inside of the house to expose the window screen track. Tilt screen at an angle and feed it completely through the window opening

INSTALLATION


STEP 1

Position the screen with the vinyl adapter at the top. Slide one side completely into the window screen track.




STEP 2

Firmly hold the bottom in place and lift the opposite side until the frame clears the opening of the screen track.




STEP 3

Pull the screen toward you and seat it into the screen track.



STEP 4


Lower the screen until it rests against the sill and close your window.



REMOVAL


STEP 1

Raise the screen until you can grasp the bottom edge of the frame.




STEP 2

While holding one corner completely stationary, lift the opposite side until the frame of the screen clears the window screen track.




STEP 3

Gently push the raised side toward the outside of the window.



STEP 4

Pivot the screen outward to fully remove it from the window screen track.



SCAN QR CODE TO WATCH THE VIDEO



MORE INFO AT FLEXSCREEN.COM